Программа №3 обслуживания дорожек ФБМО ВС 19-23.11.2024	
START CLEANING	REV OIL PAD #3L
DISTANCE -> 00 00	IN FEET 00 39
OIL ONLY DUST ?	REV OIL PAD #4L IN FEET 00 40
01 = YES ->00 01	NEV OIL FAD #4L IN FEET 00 40
OIL PATTERN DIST IN FEET	ADD OIL PAD #8R
->00 45	# OF HIT 00 00
FORWARD SHIFT TO 2 _{ND}	ADD OIL PAD #7R
SPEED 00 28	# OF HIT 00 00
FORWARD SHIFT TO 3RD	ADD OIL PAD #1L
SPEED 00 34	# OF HIT 00 00
FWD OIL PAD #8 R	ADD OIL PAD #2L
INCHES 0000 0010	# OF HIT 00 00
FWD OIL PAD #7 R	DISTANCE BETWEEN
INCHES 0000 0020	HITS / FEET 00 06
FWD OIL PAD #6 R	
IN FEET 38	
FWD OIL PAD #5 R	
IN FEET 43	
FWD OIL PAD #1 L	
INCHES 0000 0010	
FWD OIL PAD #2 L	
INCHES 0000 0020	
FWD OIL PAD #3 L	
IN FEET 36	
FWD OIL PAD #4 L	
IN FEET 43	
REVERSE SHIFT TO	
3RD SPEED 00 43	
REVERSE SHIFT TO	
2 _{ND} SPEED 00 37	
REVERSE SHIFT TO	
LOW SPEED 00 25	
REV OIL PAD #8R	
INCHES 0000 0300	
REV OIL PAD #7R	
INCHES 0000 0400	
REV OIL PAD #6R	
IN FEET 00 41	
REV OIL PAD #5R	
IN FEET 00 41	
REV OIL PAD #1L	
INCHES 0000 0300	
REV OIL PAD #2L	
INCHES 0000 0400	